

DUNLOP Ready-to-Go VINYL ADHESIVE is a revolutionary spray-on adhesive, suitable for applying vinyl sheet and vinyl tile to concrete, underlayment grade plywood, metal and fibreglass substrates.

SURFACE PREPARATION

Damp-mop substrate to remove all dust. Approved substrate must be dry and free from oil, rust, paint, old adhesive residue, wax, curing compounds, sealers, hardeners, or any other materials that would interfere with the bonding of the adhesive to the substrate.

Use only DUNLOP floor levelling and patching mortars to ensure surface is flat and ready for vinyl. Imperfections in the surface may show through the vinyl.

VINYL TYPES

Vinyl sheet, vinyl tiles and vinyl planks with vinyl backing. Contact Dunlop for non-vinyl backed materials.

APPLICATION

- 1. Ensure adequate ventilation in project area. Mask the project area with painters tape and paper/plastic sheeting to protect from overspray.
- 2. Shake can well before use and ensure can is at room temperature at time of application.
- 3. Snap off blue safety tab from top of can. Hold can upright, approximately 50-76cm above the substrate, aim and pull trigger.
- 4. Move can back and forth smoothly and evenly to achieve desired results; proper coverage should resemble a heavy frost. Avoid insufficient or excessive application of adhesive. Do not overspray in patches as it may show through the vinyl. Lightly re-spray missed areas.
- 5. In order to maintain a consistent spray pattern, remove any build-up of excess adhesive from spray tip.
- 6. Take care not to overspray onto walls, windows etc. The use of a spray shield is recommended when spraying against walls, cove base, or other flooring materials. Wipe overspray with a damp cloth.
- 7. Allow adhesive to dry until there is no adhesive transfer when lightly touched with the fingertips. Working time once tacky is 3 hours. Whilst adhesive is drying, ensure the surface is not contaminated by dust, dirt etc.
- 8. Roll vinyl into adhesive with roller within 1 hour of the vinyl being laid. Apply pressure onto the floor with a heavy roller (or equivalent pressure) evenly across the floor.
- 9. Once rolled, the floor is ready for immediate use.

HEAT WELDING

Flooring may be heat welded 1 hour after installation of the vinyl.

CAUTION

Contents under pressure. Store between 10°C to 50°C. AVOID FREEZING. Keep out of the reach of children. Avoid contact with skin, face or eyes. Do not ingest. PRESSURISED DISPENSER, PROTECT FROM SUNLIGHT AND DO NOT EXPOSE TO TEMPERATURES EXCEEDING 50°C. DO NOT PIERCE OR BURN, EVEN AFTER USE. Intentional misuse by deliberately concentrating and inhaling contents of aerosol containers can be harmful or fatal. Not suitable for use with cushion-backed flooring products. Determine adhesive compatibility by performing bond tests recommended by flooring manufacturer. Avoid application of vinyl tiles and planks in areas exposed to prolonged sun heat or high temperatures.



Skin: Remove adhesive from skin with warm soap and water.

Eye Contact: Flush eye with large quantities of water for 15 minutes and seek medical attention. If ingested, do not induce vomiting, give water to dilute, and seek medical attention immediately. DO NOT concentrate vapours and inhale fumes. Use only with proper ventilation. For advice, contact a Poisons Information Centre (13 11 26) in Australia or 0800 764 766 in New Zealand or contact a doctor.

GUARANTEE

DUNLOP products are generally warranted for 10 years when installed to relevant Australian standards, applicable DUNLOP specification, technical data sheet and instruction for application and use. While we assure customers the high standard and quality of our products and services, we accept no liability for any loss or damage which arises from particular site conditions, poor handling and storage, or installation by unqualified or unskilled applicators.

SHELF LIFE

A shelf life of 12 months is expected when stored in a dry place in original unopened container at 25°C.

DISPOSAL

Bleed off excess pressure. Please recycle the aluminium can.

ARDEX AUSTRALIA PTY LTD ABN 82 000 550 005 7/20 Powers Rd SEVEN HILLS NSW 2147 Ph +61 2 9851 9199 Fax +61 2 9674 5621

ARDEX NEW ZEALAND LTD 32 Lane St WOOLSTON CHRISTCHURCH Ph +64 3 373 6900 Fax +64 3 3849 779



DUNLOF Ready-10-GO VINYL ADHESIVE		
GUIDE	A space of the space of th	
Conc • Store adhesive at a minimum temperature 20°C for 24 hours prior to installation. • Shake aerosol can well.	• If overspray occurs, it may be removed with a damp doth while the adhesive is still wet.	
 Compounding areas are clean and distribution of the state of the state	Allow adhesive to dry until there is no adhesive transfer when lightly touched (approximately 30 minutes). High humidity and/or low temperature increases tack time.	
Protect from overspray with a spray shield, drop cloths, paper or masking. So-76cm So-76cm and pull trigger.	• Once tacky, vinyl can be laid for up to 3 hours: While open, ensure that adhesive is not contaminated by dust.	

TECHNICAL DATA

Chemical Type	Water based acrylic blend
Appearance	Milky white frost bubbles
Odor	Sweet mild odor
Flash Point	Will not burn
Storage	Do not subject to freezing temperatures
Shelf Life	12 months in original unopened container
Open Time	3 hours (do not lay vinyl into adhesive after this time)
Dry Time	Once adhesive is dry to touch (10-40 minutes)
VOC Content	<0.0g/ml calculated
Traffic Allowance	Immediate
Underfloor Heating Systems	Yes